

1.221





VCM.













seit 30 Jahren
service@vcm-gruppe.de



Aufbauanleitung

Artikel:

VCM CD/DVD Möbel "Luxor"



1.7  x17	1.6  x1	1.8  x9	1.32  x124	1.5 3,5x16mm  x34
1.54  x1	1.55  x1	1.59  x2	1.2  x4	
1.21  x4	1.39  x4	1.14  x13		





5



6

Vorderseite

Rückseite



1	Beschlag / Ferrure		1
3	860**	390**	1
4	860**	390**	1
5	260*	130	30
2	882**	305	2
7	882**	305	2
8	871**	270**	2
6	882	260	3
glass	871**	288**	1

